


CLEANING AND HANDLING FILTERS

Handle coated pieces by the edges only. Clean gently only if necessary. Loose particles should be removed with a bulb puffer or filtered, pressurized air cleaner. If necessary, gently wipe surface using anhydrous alcohol and lint free lab towels. Use a new surface of towel with each wipe.

AVOID TOUCHING OR WIPING A/R COATED OR METAL MIRROR SURFACES

AVOID HANDLING EXPOSED COATINGS WITH BARE FINGERS





CLEANING AND HANDLING FILTERS

Handle coated pieces by the edges only. Clean gently only if necessary. Loose particles should be removed with a bulb puffer or filtered, pressurized air cleaner. If necessary, gently wipe surface using anhydrous alcohol and lint free lab towels. Use a new surface of towel with each wipe.

AVOID TOUCHING OR WIPING A/R COATED OR METAL MIRROR SURFACES

AVOID HANDLING EXPOSED COATINGS WITH BARE FINGERS

